

AS/NZS 3760:2010 TESTING INTERVAL TIMETABLE

(CAUTION: This page must be read in conjunction with AS/NZS3760:2010 as a whole, and particularly clause 2.1).

		Specifications):				
	Interval between inspection and tests						
Type of Environment and/or Equipment	Class of Equipment		Residual Current Devices (RCDs)				
	Class I (protectively earthed)	Class II (doubled insulated)	Push Button test - by user		Operating timed and push - button test		Cord sets and power boards
			Portable	Fixed	Portable	Fixed	
Factories, workshops, places of work or repair, manufacturing, assembly, maintenance or fabrication	6 months	6 months	Daily or before every use	6 months	12 months	12 months	6 months
Environment where the equipment or supply flexible cord is subject to flexing normal urse OR is open to abuse OR is in a hostile environment	12 months	12 months	3 months	6 months	12 months	12 months	12 months
3. Environment where the equipment or supply cord is NOT subject to flexing in normal use and is NOT open to abuse and is NOT in hostile environment	5 years	5 years	3 months	6 months	2 years	2 years	5 years
Residential type areas of: hotels, residential institutions, motels, boarding houses, halls, hostels, accommadation houses, and the like.	2 years	2 years	6 months	6 months	2 years	2 years	2 years
5. Equipment used for commercial cleaning	6 months	12 months	3 months	n/a	12 months	n/a	12 months
6. Hire Equipment: Inspection	Prior to hire	Including Push Button test by hirer prior to hire	n/a	n/a	Prior to hire		
Test and Tag	3 months	n/a	3 months	12 months	3 months	1	
7. Repaired, serviced and second-hand equipment	After repair or service which could affect electrical safety, or on reintroduction to service						